

Boss Coupling System.....152 - 163

Overview	152
Ground joint.....	153 - 155
Complete couplings with female spud.....	153
Stems	153
Wing nuts	154
Knurled nut	154
Female spuds	154
Male spuds	155
Double spuds.....	155
Holedall®	155
Adapters	156
Wing nut caps.....	156
Washer seal	157 - 158
Complete couplings with female spud.....	157
Stems	157
Female spuds	157
Male spuds	158
Double spuds.....	158
Washers	158
Male stems	159 - 160
LP male stems.....	160
Menders.....	160
Spud x hose shank.....	160
Clamps.....	161 - 162
2 Bolt type, 2 gripping fingers.....	161
4 Bolt type, 2 gripping fingers.....	161
4 Bolt type, 4 gripping fingers.....	162
6 Bolt type, 3 gripping fingers.....	162
6 Bolt type, 6 gripping fingers.....	162
Ground joint air hammer couplings	163

Boss Low Pressure System (LPS)....164 - 178

Components overview	164
Frac fittings	165 - 166
Complete male / female assembly.....	165
Female	165
Male with nut.....	166
Suction service fittings	166
O-rings.....	166
Short ferrules	166
Hammer union.....	167 - 169
Nuts.....	167
One-Piece	167
Two-Piece.....	167
Three-Piece	167
100-Series.....	168
200-Series.....	168
206-Series	168
Caps and plugs.....	169
One-Piece adapters.....	170 - 171
Flange	170 - 171

Straight.....	170
Short.....	170
45° Elbow	170
150# Flange to weld.....	171
125# Flange x male NPT.....	171
Port adapter.....	171
Elbows.....	171
King Crimp® style	172 - 173
Large sleeves.....	172
Heavy duty	173
Combination nipples	173
Ferrules	173
Butterfly valves.....	174
Frac pump elbow adapters.....	175
Vent-Lock® safety cam and groove couplings.....	176 - 178
Type A	176
Type C	176
EZ Boss-Lock type C	176
Type D	177
Type E.....	177
Dust caps.....	177
Dust plugs.....	177
EZ Boss-Lock type H dust caps.....	177
Accessories	178
Handles	178